



LAWRENCE[®]
HARDWARE INC.

INSTALLATION INSTRUCTION FOR
LH5510 PANIC/ FIRE RIM EXIT DEVICES.

These instructions are presented in step by step sequence and include a template to tape to your door and frame as an aid to preparing for device mounting.

Please read it thoroughly before installation.

Note : Template dimensions are shown in inches. See attached Metric Conversion Table if necessary.

TOOLS REQUIRED	METAL	WOOD	
	<p>#7 1/4"-20</p>	<p>1/8"</p>	<p>Wood and Metal Screws</p> <p>For wood, drill 1/8" hole</p> <p>Machine Screws</p> <p>#7 Drill, 1/4"-20 Tap</p>

Not to Scale

The use of non-clutching impact drivers to install this hardware will automatically void the warranty.