LHR DOOR Backset 1 13/16" **INSIDE FACE GRADE 1 NARROW STILE** (46mm) PLACE THIS SIDE ON DOOR **CVR EXIT DVICE TEMPLATE** (19mm)(FOR PANIC AND FIRE RATED DEVICCES) 1/8" Mounting Holes: A, B 2 places (3mm)REV: 01, 03/2011 Metal Door R For Mounting Screws – Drill/Tap for 1/4-20 machine screws For Sex Bolts – Not available for this model DOOR EDGE Wood Door: Do not recommend to use this model. Mounting Holes: C, D 2 places For Trim Only – Drill Ø 5/16" (8 mm) holes inside Drill Ø 1/2" (13 mm) holes outside 2 Mounting Holes : Metal Door - Drill/Tap for #12-24 1 1/2" <u>Z</u> (38mm) machine screws
Wood Door – 1/8" (3 mm) Pilot Drill SIDE for wood screws 3 1/4" Trim Actuating Shaft Hole: PLACE THIS (83mm) Drill Ø 1/2" (13 m m) through hole for BE & CE trims For NL trim hole r equirement, see its template 9/16" (Not required for dummy trim) (14mm)AND FOLD, 2 7/8" 1 3/16" (73mm)G of Device MARK HORIZONTAL CENTERLINE ON (30mm) DOOR AND DOOR STOP ら Device y 19/32" (15mm) D (നമ്പട്ട) a 1/4 B **LAWRENCE**° HARDWARE INC. Mark mounting holes through (mm8£) end cap bracket after device 11/5" **TEMPLATE FOR** is cut and level. LH8750 NARROW STILE CVR EXIT DEVICES. LH8550 NARROW STILE CVR EXIT DEVICES. B (mme) NOTE: 1. Device horizontal centerline to be 40" from finished floor. Gap of 1/4" (6 mm) between door bottom and finished floor is required. FOLD HERE (ww61) For outside trim preparation, please refer to appropriate trim template. a7/E Glass bead kit available when required, it is sold separately. (ww9t) **INSIDE FACE** This side up is for LHR door application, RHR door application is rotated 180°. 13/16" Backset RHR DOOR