


## Template & Installation Instruction For LHFB510M Constant Latching Flush



Not to Scale

The use of non-clutching impact drivers to install this hardware will automatically void the warranty.